Stonex S999 Quick Manual







No	Item	Description
1	Satellite	Flashing red: satellites tracked, a position not calculated
	indicator	Flashing green: position calculated without a fixed
		solution
		Green: fixed solution
		Flashing green and red alternately: GNSS board abnormal
2	Bluetooth	Blue: connected
	indicator	Off: no connection
3	Datalink	Green: datalink setting success
	indicator	Flashing green: data in normal transmission
		Flashing blue: raw data recording, flashing frequency
		according to the sampling interval
4	Battery	Green: charge level between 30% and 100%
	indicator	Flashing green: charge level between 10% and 30%
		Flashing red: charge level lower than 10% with a warning
		beep
		Device off while charging:
		Green: charge completed
		Red: in charge
5	Power	Power on: keep pressed until you hear a beep. After three
	button	short beeps, the device is ready to work
		Current working mode: short press, if the speaker is
		enabled the device will describe the current working
		mode.
		Power off: keep pressed until all LED start to flash, release
		then short press
		Self test: keep pressing until all LED start to flash, release
		then long press until the LED stops flashing. The device
		will test the internal modules. If an error is found the
		device will start to beep, to stop it short press the power
		button. Please contact your local dealer if this happens.
	1	1



1	USB type-C	Charging port.
	port	It can be used to access the device's internal memory if
		connected to a PC using a USB to type-C cable.
2	Sim card slot	Slot for Nano SIM Card, the card must not have a PIN
		code, insert the card while the device is off. The card is
		locked in by sliding the metal cover. The rubber cover is
		held by pressure.
3	TNC	Screw connector for UHF module external antenna. The
	connector	rubber cover is held by pressure.
	for UHF	,,
	antenna	
4	5/8'	Screw connector for support
	Connector	
5	Serial	Serial number of the device
	Number	
6	Bottom	Camera for visual stakeout
	camera	
	İ	



No	Item	Description
1	Frontal	Camera for visual stake out and measurements
	camera	

Standard Accessories:



Carrying case

Cable

1 Connection cable USB type A – USB type C

Power supply

- 1 Power adaptor with EU/UK/US/AU power socket, model: DSA-45PDH
- 1 Charging cable USB type-C USB type-C